



DF-SA130 - RV Shower Head and Hose



MAINTENANCE AND CLEANING

Cleaning Tips: The finish on your product is designed to retain its beautiful sheen for years. To maintain the original look of the finish, a little care and caution should be used. We recommend the use of mild soap and water to clean the product.

THE USE OF ABRASIVE CLEANERS MAY SCRATCH THE FINISH OR CAUSE OTHER DAMAGE.

RECOMMENDED TOOLS AND MATERIALS

- ◆ Screwdriver

BEFORE YOU BEGIN

There are a variety of things to do before installing any new plumbing system into your RV. Before you begin work make sure you:

- ◆ Shut off the main water supply
- ◆ Cover your drain to prevent loss of parts
- ◆ Observed any local plumbing codes
- ◆ Inspect fixture for damage - Replace as necessary

* Dura Faucet reserves the right to make any revisions in the design of products without notice.

INSTALLATION

1 Mount Large Shower Wand Bracket

Using the screws provided, mount the larger shower wand bracket above the faucet at desired height.

2 Attach PVC Hose to Shower Wand

Attach the PVC hose to the bottom of the shower wand and set into bracket.

3 Mount Small Shower Wand Ring Bracket and Place PVC Hose Through it

Using the screws provided, mount the smaller ring bracket and then slip PVC hose through.

4 Attach PVC Hose to Faucet's Diverter

Attach PVC hose to faucet's diverter. You can now start enjoying your new Dura Faucet Shower Head.

SPEC DRAWING / PARTS

- 1** ABS Plug (1)
- 2** Stainless Steel Screw (1)
- 3** ABS Cover (1)
- 4** ABS Seat (1)
- 5** Rubber O-Ring (1)
- 6** ABS Handle (1)
- 7** POM Cover (1)
- 8** Rubber O-Ring (2)
- 9** POM Flow Axle (1)
- 10** Rubber Washer (2)
- 11** POM Inter (2)
- 12** Brass Core Tube (2)
- 13** ABS Loudspeaker Head (2)
- 14** PVC Hose (1)

