

SAFE T RAIL FOR MOTORHOMES

QUALIFIER

SP56-632



Height: 28.9"

Total Width (with bolts): 2.75"

Mounting Width: 2-3/16"

Depth: 2.5" (closed) 16.25" (open)

BEFORE YOU BEGIN

Please note these compatibility limitations:



The **Safe-T-Rail** is designed to work on laminated walls, assuming there is sufficient backer material behind the wall.

Note: For proper screw retention, the mount surface must have sufficient frame backer for the mounting screws to bite into.



Above. Beyond. Always.

574.293.1581 • www.MORryde.com

MEASURING

STEP 1

CHECK FOR VERTICAL CLEARANCE

Depending on the make/model of the motorhome RV, the mounting height will vary. The Safe-T-Rail requires a minimum of 29" of clearance from bottom of the mount bracket to any potential obstruction. In cases where a rub rail exists at the belt line of the RV, the rail may be mounted above said belt line, assuming that this does not create a disproportionate functional relationship between the steps and the rail.



- Note that the Safe-T-Rail should cover old screw holes if replacing an existing grab handle.
- Not recommended to replace lighted handrails.

STEP 2

CHECK FOR HORIZONTAL CLEARANCE

The motorhome Safe-T-Rail requires a minimum of 3" from the outer edge of the door to any potential obstruction for the rail to fit and function properly.

Note: If the RV is equipped with baggage doors, use of the Safe-T-Rail (in the open position) may prevent the baggage door from fully opening.



- Must mount to the edge of the door frame with no interference or obstructions.