



SNAPJACK™ QD

INSTALLATION INSTRUCTIONS



Warning

Please read through the full instruction sheet before beginning any work.

Do not use power tools for the installation of SnapJack™. Over tightening hardware can result in permanent damage to your scissor jacks, and to your SnapJack™.

Important Note:

If you are not comfortable taking apart and rebuilding your scissor jacks, it is strongly recommended to have the SnapJacks installed by a professional mechanic or RV Service Center.

SnapJack installation should be performed on a hard, level surface (concrete or asphalt). Wheel chocks should be placed in front of and behind the RV/Trailer wheels for additional safety.

Installation is greatly simplified by installing SnapJacks on new scissor jacks.

If installing on existing jacks, ensure they are in good mechanical condition, with no damage, bends, etc.

Be sure to thoroughly clean and dry your used scissor jacks prior to installing your SnapJack Adapter Feet.

Required Installation Tools:

- **Socket wrench & 9/16" socket**
- **9/16" wrench**
- **Jack Crank Handle**

Note: Socket and wrench sizes for removing the OEM bolts will vary by jack brand/model.

Recommended/Optional Tools:

- **Rubber Mallet**
- **Gloves**

Note: If you are installing your SnapJacks on a new set of scissor jacks, it is recommended to do this before you mount the jacks to your RV/trailer. The process is the same as described below, but you can work on a bench/table, with the jack flipped over (foot facing up).

Hardware Selection

Your SnapJacks come complete with different mounting hardware components to allow for usage with LCI Quick Drop, PSX1, & PSX2 drop down stabilizer jacks. The exact configuration will vary depending on your stabilizer jack model, year of manufacture, and condition.

- **LCI Quick Drop:** Each foot will require a single $\frac{3}{8}$ " bolt, four of the $\frac{3}{4}$ " spacer bushings, and a single $\frac{3}{8}$ " locknut.
- **LCI PSX1:** Each foot will require a single $\frac{3}{8}$ " bolt, zero-to-four of the washers, and a single $\frac{3}{8}$ " locknut.
- **LCI PSX2:** Each foot will require a single $\frac{3}{8}$ " bolt, zero-to-four of the washers, and a single $\frac{3}{8}$ " locknut.

SNAPJACK™ QD

INSTALLATION INSTRUCTIONS

1. Lower the stabilizer jack until the foot almost touches the ground.
2. Remove the locknut from the bolts on the stabilizer jack foot.
3. Remove the bolt from the stabilizer jack foot, and any washers (PSX) or spacer bushings (Quick Drop) that may be present. Note: A rubber mallet may be used to assist in gently knocking the bolt out if required.
4. Carefully remove the stabilizer jack foot. Note: The stabilizer foot and original hardware will can be set aside, as they will not be re-used.
5. Place your SnapJack QD on the ground next to your stabilizer jack. You are going to want to raise/lower your scissor jack slightly so the bolt holes in the stabilizer jack are at the same height as the bolt holes in the SnapJack.
6. Move your SnapJack along the ground and slide the tabs along either side of the stabilizer jack, lining up the bolt holes.

7. Install the first bolt, passing it through the SnapJack, the required hardware, and the stabilizer jack. Depending on the model and year of your stabilizer, the hardware configuration will look as follows:
 - **Quick Drop:** Pass the bolt through the SnapJack tab, and one of the $\frac{3}{4}$ " bushings. Slide the bolt through the outer Quick Drop leg (black), through another $\frac{3}{4}$ " bushing, and then through the inner Quick Drop leg (silver). Continue the pattern in reverse, passing the bolt through another $\frac{3}{4}$ " spacer, the other side of the outer Quick Drop leg, a forth $\frac{3}{4}$ " spacer, and finally the second tab of the SnapJack. Note: You may need to gently tap the bolt through with a rubber mallet.
 - **PSX1/PSX2:** *Note: Due to a variation in manufacturing tolerances and materials, the width of the PSX series stabilizer arms can vary.* This variance will be made up with the use of the included washers, which will be placed between the stabilizer arm and the SnapJack tabs. You may require anywhere from 0-4 washers, and we recommend having them on both sides if possible. Pass the bolt through the SnapJack tab, and through the washer(s) as required, before passing the bolt through the first side of the PSX arm. Add any additional required washers as you pass the bolt through the second side of the arm, and before you pass it through the second SnapJack tab.



8. Using your hand, thread the locknut onto the back of the bolt a few turns until resistance is felt.
9. Place your 9/16" wrench over the bold head, and your 9/16" socket wrench over the nut. Tighten until just snug. You want your SnapJack to have a free range of motion without having any excessive play. **DO NOT OVER-TIGHTEN.**
10. Cycle your stabilizer jacks through a full range of motion a few times to ensure that no binding or issues are present.
11. Repeat the process for the remaining stabilizer jacks.
12. Enjoy the added stability, grip, protection, and style that your new SnapJack QD's provide!

NOTE: Always ensure the safety chain provided with the LCI Quick Drop stabilizers is used when the stabilizer jacks are in their raised travel position.

Warranty

Origen RV Accessories LTD offers a 2-year manufacturer's warranty on both performance and defects in material and workmanship.

Should your product fail within a 2-year time frame, Origen RV Accessories LTD will replace your pad free of charge. Warranty coverage does not extend to acts of God, misuse of product, improper installation, and damage from external events like accidents.

Conditions

- Register your product warranty first in order to be able to file a claim later on, if necessary. For more information, visit rvsnappad.com/pages/general-warranty.
 - If your SnapJack™ were purchased from Amazon, we encourage you to contact them for your replacement/refund.
 - Origen RV Accessories LTD will replace any defective products within the acceptable 2-year window, starting from the purchase date.
 - To submit your warranty claim please visit rvsnappad.com/pages/file-a-claim.
 - Proof of purchase is required for any warranty redemption on your pads.
 - If you need to return your UNUSED pads within 30 days of purchase please contact our Customer Service Agents at info@rvsnappad.com.
 - Be advised the product must be shipped back to Origen RV Accessories LTD at your cost, meaning you pay the shipping charges for returning any pads.
 - Once shipped, email your tracking number to info@rvsnappad.com for confirmation and then your refund will be issued.
-

Disclaimers

- The SnapJack™ adapter kit and RV SnapPads are an aftermarket RV accessory, and as such, it is the responsibility of the RV owner to ensure they are an appropriate and safe addition to their RV.
- Each RV has unique design considerations. It is the responsibility of the RV owner to confirm their SnapJack™ have adequate clearance for any moving parts and will not hinder the functionality of any other system.
- Origen RV Accessories LTD shall not be liable for any special, incidental, indirect or consequential damages whatsoever (including but not limited to, labor, installation, charges, damage to associated equipment, RV, trailer, towing or following vehicle) arising from the use or inability to use or install the product.
- Use extreme caution when installing and using SnapJack™. Origen RV Accessories LTD is not responsible or liable in any way for any indirect or direct injury sustained during installation or future use of the product.
- Origen is not responsible for any issues arising from the use of our products on non-compatible systems.



Scan for the Install Video

View a full, detailed installation guide of SnapJack QuickDrop.

Questions? Concerns?

1-886-923-9538 | info@rvsnappad.com | rvsnappad.com