




Product Instruction Booklet

Contents:

Page No.




Pack Mount: This the set up that most people start with.

1




CARB Spout: Designed to reduce the chance of spilling as well as reducing the emissions of harmful vapors into the environment.

2




DLX T-Handle: Uses less arm strength and allows for extra tightening power.

2




LOX T-Handle: Enables security by incorporating a locking mechanism into the handle, preventing anyone from removing your Fuel Pack without having the key.

3




Pack Mount Extension: Enables two Fuel Packs to be mounted on top of each other.

3-4




Universal Mounting Plate: Allows for mounting of multiple size Fuel Packs and on many different surfaces.

4



Pack Mount L-Bracket: Excellent for mounting next to storage containers or when an upright position is desired.

5



RZR Mounting Plate: Allows for mounting Fuel Packs to 1 ½" diameter bars (commonly found on ATVs).



5

Pack Mount

Step 1 – If mounting to a surface with an accessible backside (such as a thin walled container), do **Option 1** or **2**. If mounting to a surface where backside is not accessible (such as a stud on a garage wall), do **Option 3**.

Option 1 – Discard the Round Mounting Disk and mount the Upright Base directly to the surface using the 2 hex bolts provided (see **Figure 1**).


Or, attach the Round Mounting Disk to the Upright Base using the 2 hex bolts provided then use 4 carriage bolts, nuts, and washers provided to attach the Round Mounting Disk to the surface (see **Figure 2**).





Option 2 – If you are worried that the Pack Mount might bend your mounting surface, use the Backing Plate (sold separately) in conjunction with the Round Mounting Disk and Upright Base to support the backside of the surface as shown (see **Figure 3**).

Option 3 – Discard the Round Mounting Disk and mount the Upright Base directly to the surface with two long screws (not included) through the two outer holes in the Upright Base (see **Figure 4**).

Or, attach the Round Mounting Disk to the Upright Base using the 2 hex bolts provided, then use two shorter screws (not included) to attach the Round Mounting Disk and Upright Base to the surface through the two additional holes in the Round Mounting Disk (see **Figure 5**).



Step 2 – Once upright base has been mounted to the surface, mount Fuel Pack onto base and insert the T-Handle into threads in the top of the Upright Base then tighten by twisting clockwise to desired tension (see **Figures 6** and **7**).



CARB Spout

Step 1 – Untwist the cap and remove the Spout (see **Figure 8**).

Step 2 – Replace the Spout in the reverse direction and retighten the cap (see **Figure 9**).

Step 3 – Before pouring from your Fuel Pack, pull firmly down on the midsection collar to release any pressure buildup in the Fuel Pack (see **Figure 10**).

Step 4 – When ready to pour, catch the collar lip on the tank opening and push down to ensure that the collar slides back, allowing fuel to flow into the tank and air to flow into the Fuel Pack (see **Figure 11**).

Step 5 – When the tank is full, the airflow into the Fuel Pack will be shut off which stops the fuel flow. As you pull the Spout out of the opening, the Spout will seal internally because the collar has retracted.




Figure 8




Figure 9




Figure 10




Figure 11

DLX T-Handle

Step 1 - Insert DLX T-Handle into the Upright Base then tighten to desired tension while keeping the indents on the underside of the Lower Wing aligned with the Fuel Pack bumps (see **Figures 12-14**).




Figure 12




Figure 13




Figure 14

LOX T-Handle

Step 1 – Insert the LOX T-Handle into the Upright Base then tighten to desired tension while keeping the indents on the underside of the Lower Wing aligned with the Fuel Pack bumps (see **Figures 15** and **16**).

Figure 15





Figure 16




Figure 17

Step 2 - Ensure that the square bottom of the Lower Wing has been snugly inserted into the hole of the Fuel Pack and that the Lower Wing and the Upper Handle are aligned (see **Figure 17**).

Step 3 - Insert lock into the hole and push down until you hear the lock snap into place. The handle is now locked (see **Figure 18** and **19**).




Figure 18




Figure 19




Figure 20


Step 4 - To remove lock, insert key into lock, twist key and pull out (see **Figure 20**).

Note: To ensure extended life, lubricate the lock periodically.

Pack Mount Extension

Step 1 - Insert Extension Handle into the Upright Base then tighten while keeping the indents on the Lower Wing (see **Figure 21**)

Figure 21



aligned with the bumps on the Fuel Pack (see **Figure 22**) until the Extension Handle is sufficiently tight and the Upper Handle and Lower Wing are perpendicular to each other (see **Figure 23**).




Figure 22




Figure 23

Step 2 - Mount another Fuel Pack onto the extension handle (see **Figure 24**).




Figure 24

Step 3 - Tighten T-Handle or other handles (LOX or DLX) to desired tension (see **Figure 25**).




Figure 25

Universal Mounting Plate

Step 1 – If using the Universal Mounting Plate for a 4-gallon Fuel Pack or a combination of 2-gallon Fuel Packs (for multiple 1-gallon Fuel Packs, only do step **A** but attach tightly):

A – Attach Upright Bases loosely to Universal Mounting Plate using the hardware included with the Upright Bases (see **Figure 26**).




Figure 26

B – Mount the Fuel Pack(s) onto the loosely attached Upright Bases (see **Figure 27**).




Figure 27

C – While the Fuel Pack(s) are still mounted, tighten the Base bolts from the underside of the Universal Mounting Plate (see **Figure 28**).




Figure 28

Step 2 – Once the Upright Bases have been attached properly, remove the Fuel Pack and attach the Universal Mounting Plate to a desired surface using any arrangement of holes in the Universal Mounting Plate and the provided hardware (see **Figure 29** and **30**).




Figure 29




Figure 30

Pack Mount L-Bracket

Step 1 – Attach the L-Bracket to a desired surface using the hardware provided (see **Figure 31**).

Step 2 – Attach Upright Base to either side of the L-Bracket using the hardware included (see **Figures 32 and 33**).




Figure 31




Figure 32




Figure 33

RZR Mounting Plate

Step 1 – Wrap the RZR Mounting Plate around the bar and use to hose clamp to stabilize the Mounting Plate on the bar (see **Figure 34**).

Step 2 – Attach Upright Base to the RZR Mounting Plate using the hardware included (see **Figures 35 and 36**).




Figure 34




Figure 35




Figure 36

For additional functionality, two RZR Mounting Plates can be used to secure a 4-gallon or two combination 2-gallon Fuel Packs similar to the Universal Mounting Plate.